

КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER SSD AC 890

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

	1		2	3	4	5		6	7		8	9	10	11	12
Order example	890CD	-	23	1300	B	0	-	B	00	-	1	A	0	0	0

1 Drive Type
890CD Common Bus Drive

2 Voltage
23 230 V Nominal
43 400 V Nominal
53 500 V Nominal

3 & 4 Current Rating and Frame
1300 B 0.55 kW (230 V Nominal Supply)
1550 B 1.1 kW (230 V Nominal Supply)
1700 B 1.5 kW (230 V Nominal Supply)
2110 B 2.2 kW (230 V Nominal Supply)
2165 B 4.0 kW (230 V Nominal Supply)
2240 C 5.5 kW (230 V Nominal Supply)
2300 C 7.5 kW (230 V Nominal Supply)
1200 B 0.55 kW (500 V Nominal Supply)
1350 B 1.1 kW (500 V Nominal Supply)
1450 B 1.5 kW (500 V Nominal Supply)
1600 B 2.2 kW (500 V Nominal Supply)
2100 B 4.0 kW (500 V Nominal Supply)
2120 B 5.5 kW (500 V Nominal Supply)
2160 B 7.5 kW (500 V Nominal Supply)
2240 C 11 kW (500 V Nominal Supply)
2300 C 15 kW (500 V Nominal Supply)
2390 C 18.5 kW (500 V Nominal Supply)
2450 D 22 kW (500 V Nominal Supply)
2590 D 30 kW (500 V Nominal Supply)

2730 E 37/45 kW (400 V / 500 V Nominal Supply)
2870 E 45/55 kW (400 V / 500 V Nominal Supply)
3105 F 55/75 kW (400 V / 500 V Nominal Supply)
3145 F 75/90 kW (400 V / 500 V Nominal Supply)
3156 F 90/110 kW (400 V / 500 V Nominal Supply)
3156 F 90 kW (500 V Nominal Supply)
3180 F 90 kW (500 V Nominal Supply)

5 Auxiliary Supply
0 None
1 115 V single phase (Frame F only)
2 230 V single phase (Frame F only)

6 Brake Switch
0 Not Fitted

7 Special Options
00 Not Fitted
07 Active Front End ('Y' caps removed Frames E & F only)
XX Documented special options 01-99, (contact your local sales office)

8 Performance
1 Advanced
2 High

9 Language
A English (50 Hz)
B English (60 Hz)

10 Option F
0 Not Fitted
1 SinCos Encoder (Endat 2.1)
3 Incremental Quadrature Encoder
5 Resolver
6 Resolver feedback with repeater output
7 8902/M1 Sin/Cos Registration

11 Option A
0 Not Fitted
N CANopen
C ControlNET
D DeviceNET
H Ethernet IP
T Modbus/TCP
P Profibus
F Profinet
S RS485 / Modbus
E Encoder with repeater output
R Analogue Input
7 8903/M1 Sin/Cos Registration

12 Option B
0 Not Fitted
A Firewire 1394A
X SP- Peer to Peer Communications (Not available if N or D selected in Option A)
E Encoder with Repeater Output
R Analogue Input Option

КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER SSD AC 890

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

AC890SD – Stand Alone Drive

	1		2	3	4	5		6	7		8	9	10	11	12
Order example	890SD	-	43	2730	B	0	-	B	00	-	1	A	0	0	0

1 Drive Type

890SD Standalone AC890 Drive

2 Voltage

23 230 V Nominal
43 400 V Nominal
53 500 V Nominal

3 & 4 Current Rating and Frame

1300	B	0.55 kW	(230 V Nominal Supply)
1200	B	0.55 kW	(500 V Nominal Supply)
1550	B	1.1 kW	(230 V Nominal Supply)
1350	B	1.1 kW	(500 V Nominal Supply)
1700	B	1.5 kW	(230 V Nominal Supply)
1450	B	1.5 kW	(500 V Nominal Supply)
2110	B	2.2 kW	(230 V Nominal Supply)
1600	B	2.2 kW	(500 V Nominal Supply)
2165	B	4.0 kW	(230 V Nominal Supply)
2100	B	4.0 kW	(500 V Nominal Supply)
2240	C	5.5 kW	(230 V Nominal Supply)
2120	C	5.5 kW	(500 V Nominal Supply)
2300	C	7.5 kW	(230 V Nominal Supply)
2160	C	7.5 kW	(500 V Nominal Supply)
2240	C	11 kW	(500 V Nominal Supply)
2300	C	15 kW	(500 V Nominal Supply)
2390	C	18.5 kW	(500 V Nominal Supply)
2450	D	22 kW	(500 V Nominal Supply)
2590	D	30 kW	(500 V Nominal Supply)
2730	E	37/45 kW	(400 V / 500 V Nominal Supply)
2870	E	45/55 kW	(400 V / 500 V Nominal Supply)
3105	F	55/75 kW	(400 V / 500 V Nominal Supply)
3145	F	75/90 kW	(400 V / 500 V Nominal Supply)
3156	F	90/110 kW	(400 V Nominal Supply)
3156	F	90 kW	(500 V Nominal Supply)
3180	F	90 kW	(400 V Nominal Supply)
3216	G	110/132 kW	(400 V Nominal Supply)
3250	G	132/150 kW	(400 V Nominal Supply)
3316	G	160/180 kW	(400 V Nominal Supply)
3361	G	180/220 kW	(400 V Nominal Supply)
3375	H	200/250 kW	(400 V Nominal Supply)
3420	H	220/250 kW	(400 V Nominal Supply)
3480	H	250/300 kW	(400 V Nominal Supply)
3520	H	280/315 kW	(400 V Nominal Supply)
3590	J	315/355 kW	(400 V Nominal Supply)

5 Auxiliary Supply

0 None
1 115 V single phase (Frame F - J only)
2 230 V single phase (Frame F - J only)

6 Brake Switch

0 Not Fitted

7 Special Options

00 Not Fitted
07 Active Front End ('Y' caps removed Frames E & F only)
XX Documented special options 01-99, (contact your local sales office)

8 Performance

1 Advanced
2 High

9 Language

A English (50 Hz)
B English (60 Hz)

10 Option F

0 Not Fitted
1 SinCos Encoder (Endat 2.1)
3 Incremental Quadrature Encoder
5 Resolver
6 Resolver feedback with repeater output
7 8902/M1 Sin/Cos Registration

11 Option A

0 Not Fitted
N CANopen
C ControlNET
D DeviceNET
H Ethernet IP
T Modbus/TCP
P Profibus
F Profinet
S RS485 / Modbus
E Encoder with repeater output
R Analogue Input
7 8903/M1 Sin/Cos Registration

12 Option B

0 Not Fitted
A Firewire 1394A
X SP- Peer to Peer Communications (Not available if N or D selected in Option A)
E Encoder with Repeater Output
R Analogue Input Option

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890CD-231300B0-000-1A3TA	890CD AC DRIVE
890CD-231300B0-000-1B000	890 COMMON BUS DRIVE
890CD-231300B0-000-2B000	890 COMMON BUS DRIVE
890CD-231550B0-000-1B000	890 COMMON BUS DRIVE
890CD-231700B0-000-1B000	890 COMMON BUS DRIVE
890CD-232110B0-000-1B000	890 COMMON BUS DRIVE
890CD-232165B0-000-1A000	890 COMMON BUS DRIVE
890CD-232165B0-000-2B000	890 COMMON BUS DRIVE
890CD-232240C0-000-1A500	890CD AC DRIVE
890CD-232240C0-000-1A5P0	890CD AC DRIVE
890CD-232240C0-000-1B000	890 COMMON BUS DRIVE
890CD-232300C0-000-1A5P0	890CD AC DRIVE
890CD-232300C0-000-1B000	890 COMMON BUS DRIVE
890CD-432730E0-000-1A000	890 COMMON BUS DRIVE
890CD-432730E0-000-1A3T0	890CD AC DRIVE
890CD-432730E0-000-1B000	890 COMMON BUS DRIVE
890CD-432730E0-000-2A000	890 COMMON BUS DRIVE
890CD-432730E0-007-1B000	890CD AC DRIVE
890CD-432870E0-000-1A000	890 COMMON BUS DRIVE
890CD-432870E0-000-1A3F0	890CD AC DRIVE
890CD-432870E0-000-1A3HA	890CD AC DRIVE
890CD-432870E0-000-1B000	890 COMMON BUS DRIVE
890CD-432870E0-007-1A000	890 COMMON BUS DRIVE
890CD-432870E0-007-1A3P0	890 COMMON BUS DRIVE
890CD-433105F1-000-1A000	890 COMMON BUS DRIVE
890CD-433105F1-007-1B000	890CD AC DRIVE
890CD-433105F2-000-1A3P0	890 COMMON BUS DRIVE
890CD-433145F1-000-1B000	890 COMMON BUS DRIVE
890CD-433145F1-000-2A000	890 COMMON BUS DRIVE
890CD-433145F1-007-1B000	890 COMMON BUS DRIVE
890CD-433145F2-000-1A000	890 COMMON BUS DRIVE
890CD-433145F2-000-1A3P0	890 COMMON BUS DRIVE
890CD-433145F2-007-1A000	890 COMMON BUS DRIVE
890CD-433156F1-000-1A000	890 COMMON BUS DRIVE
890CD-433156F1-000-1B000	890 COMMON BUS DRIVE
890CD-433156F2-000-1A000	890 COMMON BUS DRIVE
890CD-433180F1-000-1A000	890 COMMON BUS DRIVE
890CD-433180F2-007-1A000	890CD AC DRIVE
890CD-433180F2-007-1A3P0	890 COMMON BUS DRIVE
890CD-433180F2-007-1A3PA	890 COMMON BUS DRIVE
890CD-531200B0-000-1A000	890 COMMON BUS DRIVE
890CD-531200B0-000-1A0P0	890 COMMON BUS DRIVE
890CD-531200B0-000-1A10A	890CD AC DRIVE
890CD-531200B0-000-1A1H0	890CD AC DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890CD-531200B0-000-1A1P0	890 COMMON BUS DRIVE
890CD-531200B0-000-1A300	890 COMMON BUS DRIVE
890CD-531200B0-000-1A30A	890 COMMON BUS DRIVE
890CD-531200B0-000-1A30X	890CD AC DRIVE
890CD-531200B0-000-1A3F0	890CD AC DRIVE
890CD-531200B0-000-1A3HA	890CD AC DRIVE
890CD-531200B0-000-1A3N0	890 COMMON BUS DRIVE
890CD-531200B0-000-1A3P0	890 COMMON BUS DRIVE
890CD-531200B0-000-1A3PA	890 COMMON BUS DRIVE
890CD-531200B0-000-1A5N0	890CD AC DRIVE
890CD-531200B0-000-1A5P0	890 COMMON BUS DRIVE
890CD-531200B0-000-1A5PA	890CD AC DRIVE
890CD-531200B0-000-1B000	890 COMMON BUS DRIVE
890CD-531200B0-000-2A07A	890CD AC DRIVE
890CD-531200B0-000-2A50A	890CD AC DRIVE
890CD-531350B0-000-1A000	890 COMMON BUS DRIVE
890CD-531350B0-000-1A00A	890 COMMON BUS DRIVE
890CD-531350B0-000-1A0P0	890 COMMON BUS DRIVE
890CD-531350B0-000-1A10A	890 COMMON BUS DRIVE
890CD-531350B0-000-1A1FA	890CD AC DRIVE
890CD-531350B0-000-1A300	890 COMMON BUS DRIVE
890CD-531350B0-000-1A30A	890 COMMON BUS DRIVE
890CD-531350B0-000-1A30X	890CD AC DRIVE
890CD-531350B0-000-1A3F0	890CD AC DRIVE
890CD-531350B0-000-1A3HX	890CD AC DRIVE
890CD-531350B0-000-1A3P0	890 COMMON BUS DRIVE
890CD-531350B0-000-1A5N0	890CD AC DRIVE
890CD-531350B0-000-1A5P0	890 COMMON BUS DRIVE
890CD-531350B0-000-1A5PA	890CD AC DRIVE
890CD-531350B0-000-1A70A	890 COMMON BUS DRIVE
890CD-531350B0-000-1B000	890 COMMON BUS DRIVE
890CD-531350B0-000-2A30A	890 COMMON BUS DRIVE
890CD-531350B0-000-2A57A	890 COMMON BUS DRIVE
890CD-531450B0-000-1A000	890 COMMON BUS DRIVE
890CD-531450B0-000-1A00A	890 COMMON BUS DRIVE
890CD-531450B0-000-1A0P0	890 COMMON BUS DRIVE
890CD-531450B0-000-1A300	890 COMMON BUS DRIVE
890CD-531450B0-000-1A30A	890 COMMON BUS DRIVE
890CD-531450B0-000-1A30X	890CD AC DRIVE
890CD-531450B0-000-1A3F0	890CD AC DRIVE
890CD-531450B0-000-1A3N0	890 COMMON BUS DRIVE
890CD-531450B0-000-1A3P0	890 COMMON BUS DRIVE
890CD-531450B0-000-1A3PA	890 COMMON BUS DRIVE
890CD-531450B0-000-1A500	890CD AC DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890CD-531450B0-000-1A5P0	890 COMMON BUS DRIVE
890CD-531450B0-000-1B000	890 COMMON BUS DRIVE
890CD-531450B0-000-2A000	890 COMMON BUS DRIVE
890CD-531450B0-000-2A300	890CD AC DRIVE
890CD-531600B0-000-1A000	890 COMMON BUS DRIVE
890CD-531600B0-000-1A00A	890 COMMON BUS DRIVE
890CD-531600B0-000-1A0F0	890CD AC DRIVE
890CD-531600B0-000-1A0PA	890 COMMON BUS DRIVE
890CD-531600B0-000-1A0SA	890CD AC DRIVE
890CD-531600B0-000-1A1N0	890CD AC DRIVE
890CD-531600B0-000-1A30A	890 COMMON BUS DRIVE
890CD-531600B0-000-1A30X	890CD AC DRIVE
890CD-531600B0-000-1A3E0	890CD AC DRIVE
890CD-531600B0-000-1A3F0	890CD AC DRIVE
890CD-531600B0-000-1A3FA	890CD AC DRIVE
890CD-531600B0-000-1A3HX	890CD AC DRIVE
890CD-531600B0-000-1A3N0	890 COMMON BUS DRIVE
890CD-531600B0-000-1A3P0	890 COMMON BUS DRIVE
890CD-531600B0-000-1A3PE	890 COMMON BUS DRIVE
890CD-531600B0-000-1A50A	890CD AC DRIVE
890CD-531600B0-000-1A5P0	890CD AC DRIVE
890CD-531600B0-000-1A5PA	890 COMMON BUS DRIVE
890CD-531600B0-000-1B000	890 COMMON BUS DRIVE
890CD-531600B0-000-1B3H0	890CD AC DRIVE
890CD-531600B0-000-2A000	890 COMMON BUS DRIVE
890CD-531600B0-000-2A30A	890 COMMON BUS DRIVE
890CD-532100B0-000-1A000	890 COMMON BUS DRIVE
890CD-532100B0-000-1A00A	890 COMMON BUS DRIVE
890CD-532100B0-000-1A0P0	890 COMMON BUS DRIVE
890CD-532100B0-000-1A300	890 COMMON BUS DRIVE
890CD-532100B0-000-1A30A	890 COMMON BUS DRIVE
890CD-532100B0-000-1A30X	890 COMMON BUS DRIVE
890CD-532100B0-000-1A3F0	890CD AC DRIVE
890CD-532100B0-000-1A3H0	890CD AC DRIVE
890CD-532100B0-000-1A3HA	890CD AC DRIVE
890CD-532100B0-000-1A3HX	890CD AC DRIVE
890CD-532100B0-000-1A3N0	890 COMMON BUS DRIVE
890CD-532100B0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532100B0-000-1A3PA	890 COMMON BUS DRIVE
890CD-532100B0-000-1A3T0	890CD AC DRIVE
890CD-532100B0-000-1A3TA	890CD AC DRIVE
890CD-532100B0-000-1A50A	890CD AC DRIVE
890CD-532100B0-000-1A5P0	890 COMMON BUS DRIVE
890CD-532100B0-000-1A7PA	890 COMMON BUS DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890CD-532100B0-000-1B000	890 COMMON BUS DRIVE
890CD-532100B0-000-1B3H0	890CD AC DRIVE
890CD-532100B0-000-2A000	890 COMMON BUS DRIVE
890CD-532100B0-000-2A30A	890 COMMON BUS DRIVE
890CD-532100B0-000-2A3P0	890 COMMON BUS DRIVE
890CD-532100B0-000-2B7PA	890CD AC DRIVE
890CD-532120B0-000-1A000	890 COMMON BUS DRIVE
890CD-532120B0-000-1A10A	890 COMMON BUS DRIVE
890CD-532120B0-000-1A1N0	890CD AC DRIVE
890CD-532120B0-000-1A1P0	890 COMMON BUS DRIVE
890CD-532120B0-000-1A1PA	890CD AC DRIVE
890CD-532120B0-000-1A30A	890 COMMON BUS DRIVE
890CD-532120B0-000-1A30X	890CD AC DRIVE
890CD-532120B0-000-1A3H0	890CD AC DRIVE
890CD-532120B0-000-1A3HX	890CD AC DRIVE
890CD-532120B0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532120B0-000-1A3PA	890 COMMON BUS DRIVE
890CD-532120B0-000-1A5P0	890 COMMON BUS DRIVE
890CD-532120B0-000-1A5PA	890CD AC DRIVE
890CD-532120B0-000-1B000	890 COMMON BUS DRIVE
890CD-532120B0-000-2A000	890 COMMON BUS DRIVE
890CD-532120B0-000-2A3HA	890CD AC DRIVE
890CD-532120B0-000-2A50A	890 COMMON BUS DRIVE
890CD-532160B0-000-1A000	890 COMMON BUS DRIVE
890CD-532160B0-000-1A00A	890 COMMON BUS DRIVE
890CD-532160B0-000-1A1N0	890CD AC DRIVE
890CD-532160B0-000-1A1P0	890 COMMON BUS DRIVE
890CD-532160B0-000-1A300	890 COMMON BUS DRIVE
890CD-532160B0-000-1A30A	890 COMMON BUS DRIVE
890CD-532160B0-000-1A30X	890CD AC DRIVE
890CD-532160B0-000-1A3DA	890 COMMON BUS DRIVE
890CD-532160B0-000-1A3EA	890CD AC DRIVE
890CD-532160B0-000-1A3HA	890CD AC DRIVE
890CD-532160B0-000-1A3N0	890CD AC DRIVE
890CD-532160B0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532160B0-000-1A3PA	890 COMMON BUS DRIVE
890CD-532160B0-000-1A3T0	890CD AC DRIVE
890CD-532160B0-000-1A500	890CD AC DRIVE
890CD-532160B0-000-1A5P0	890 COMMON BUS DRIVE
890CD-532160B0-000-1B000	890 COMMON BUS DRIVE
890CD-532160B0-000-2A000	890 COMMON BUS DRIVE
890CD-532160B0-000-2A30A	890 COMMON BUS DRIVE
890CD-532160B0-000-2A3EA	890CD AC DRIVE
890CD-532160B0-000-2A77A	890 COMMON BUS DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890CD-532160B0-000-2B30A	890CD AC DRIVE
890CD-53216SB0-000-1A000	890 COMMON BUS DRIVE
890CD-53216SB0-000-1A1N0	890CD AC DRIVE
890CD-53216SB0-000-1A5H0	890CD AC DRIVE
890CD-53216SB0-000-2A000	890 COMMON BUS DRIVE
890CD-53216SB0-000-2A07A	890CD AC DRIVE
890CD-532240C0-000-1A000	890 COMMON BUS DRIVE
890CD-532240C0-000-1A0F0	890CD AC DRIVE
890CD-532240C0-000-1A0P0	890 COMMON BUS DRIVE
890CD-532240C0-000-1A10A	890 COMMON BUS DRIVE
890CD-532240C0-000-1A1N0	890CD AC DRIVE
890CD-532240C0-000-1A300	890 COMMON BUS DRIVE
890CD-532240C0-000-1A30A	890 COMMON BUS DRIVE
890CD-532240C0-000-1A37A	890CD AC DRIVE
890CD-532240C0-000-1A3E0	890CD AC DRIVE
890CD-532240C0-000-1A3F0	890CD AC DRIVE
890CD-532240C0-000-1A3FA	890CD AC DRIVE
890CD-532240C0-000-1A3H0	890CD AC DRIVE
890CD-532240C0-000-1A3NA	890 COMMON BUS DRIVE
890CD-532240C0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532240C0-000-1A3PA	890 COMMON BUS DRIVE
890CD-532240C0-000-1A50A	890CD AC DRIVE
890CD-532240C0-000-1A5P0	890 COMMON BUS DRIVE
890CD-532240C0-000-1B000	890 COMMON BUS DRIVE
890CD-532240C0-000-1B3P0	890 COMMON BUS DRIVE
890CD-532240C0-000-2A000	890 COMMON BUS DRIVE
890CD-532240C0-000-2A3EA	890CD AC DRIVE
890CD-532240C0-000-2A77A	890 COMMON BUS DRIVE
890CD-532240C0-000-2B30A	890CD AC DRIVE
890CD-532240C0-000-2B3PA	890CD AC DRIVE
890CD-532240C0-000-2B77A	890CD AC DRIVE
890CD-532300C0-000-1A000	890 COMMON BUS DRIVE
890CD-532300C0-000-1A0P0	890 COMMON BUS DRIVE
890CD-532300C0-000-1A300	890 COMMON BUS DRIVE
890CD-532300C0-000-1A30A	890 COMMON BUS DRIVE
890CD-532300C0-000-1A3H0	890CD AC DRIVE
890CD-532300C0-000-1A3N0	890 COMMON BUS DRIVE
890CD-532300C0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532300C0-000-1A3PA	890 COMMON BUS DRIVE
890CD-532300C0-000-1A3PE	890CD AC DRIVE
890CD-532300C0-000-1A3TA	890CD AC DRIVE
890CD-532300C0-000-1A50A	890CD AC DRIVE
890CD-532300C0-000-1B000	890 COMMON BUS DRIVE
890CD-532300C0-000-1B3H0	890CD AC DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890CD-532300C0-000-2A000	890 COMMON BUS DRIVE
890CD-532300C0-000-2B000	890 COMMON BUS DRIVE
890CD-53230SC0-000-1A50A	890 COMMON BUS DRIVE
890CD-53230SC0-000-2A000	890 COMMON BUS DRIVE
890CD-532390D0-000-1A000	890 COMMON BUS DRIVE
890CD-532390D0-000-1A3F0	890CD AC DRIVE
890CD-532390D0-000-1A3FA	890CD AC DRIVE
890CD-532390D0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532390D0-000-1A5P0	890CD AC DRIVE
890CD-532390D0-000-1B000	890 COMMON BUS DRIVE
890CD-532390D0-000-2A000	890 COMMON BUS DRIVE
890CD-532390D0-000-2A10A	890CD AC DRIVE
890CD-532390D0-000-2B000	890 COMMON BUS DRIVE
890CD-532450D0-000-1A000	890 COMMON BUS DRIVE
890CD-532450D0-000-1A30A	890 COMMON BUS DRIVE
890CD-532450D0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532450D0-000-1A3T0	890 COMMON BUS DRIVE
890CD-532450D0-000-1B000	890 COMMON BUS DRIVE
890CD-532450D0-000-1B3H0	890 COMMON BUS DRIVE
890CD-532450D0-000-2A000	890 COMMON BUS DRIVE
890CD-532450D0-000-2A30A	890 COMMON BUS DRIVE
890CD-532590D0-000-1A000	890 COMMON BUS DRIVE
890CD-532590D0-000-1A0N0	890 COMMON BUS DRIVE
890CD-532590D0-000-1A300	890 COMMON BUS DRIVE
890CD-532590D0-000-1A3H0	890CD AC DRIVE
890CD-532590D0-000-1A3N0	890 COMMON BUS DRIVE
890CD-532590D0-000-1A3P0	890 COMMON BUS DRIVE
890CD-532590D0-000-1A3PA	890 COMMON BUS DRIVE
890CD-532590D0-000-1B000	890 COMMON BUS DRIVE
890CD-532590D0-000-1B3H0	890CD AC DRIVE
890CD-532590D0-000-2A3NA	890 COMMON BUS DRIVE
890CD-532590D0-000-2B000	890 COMMON BUS DRIVE
890CD-532730E0-000-1B000	890 COMMON BUS DRIVE
890CD-532730E0-000-2A30A	890CD AC DRIVE
890CD-532870E0-000-1A000	890 COMMON BUS DRIVE
890CD-532870E0-007-1A000	890 COMMON BUS DRIVE
890CD-532870E0-007-1A1PA	890 COMMON BUS DRIVE
890CD-532870E0-007-1A3PA	890 COMMON BUS DRIVE
890CD-533145F1-000-1B000	890 COMMON BUS DRIVE
890CD-533145F1-007-2B000	890CD AC DRIVE
890CD-533145F2-000-1A000	890 COMMON BUS DRIVE
890CD-533145F2-000-1A3H0	890CD AC DRIVE
890CD-533145F2-000-1A3T0	890CD AC DRIVE
890CD-533145F2-007-1A000	890 COMMON BUS DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890CD-533145F2-007-1A1PA	890 COMMON BUS DRIVE
890CD-533145F2-007-1A3PA	890 COMMON BUS DRIVE
890CD-533156F2-007-1A000	890 COMMON BUS DRIVE
890CD-533156F2-007-1A3PA	890 COMMON BUS DRIVE
890CD-533156F2-007-1A3PX	890 COMMON BUS DRIVE
890CM-A-UK-00-00	890 CONTROL MODULE
890CM-A-US-00-00	890 CONTROL MODULE
890CS-532320B0-B00-U	890 COMM BUS SUPPLY
890CS-532540B0-B00-U	890 COMM BUS SUPPLY
890CS-533108D0-B00-U	890 COMM BUS SUPPLY
890CS-533162D0-B00-U	890 COMM BUS SUPPLY
890PX/4/0300/B/01/A	ACDRIVE BTM 400/460V
890PXCA-43215M-000-1A000	890PX Systems Drive
890PXSA-43215M-H00-1A000	890PX Systems Drive
890PXSA-43260M-B00-1B000	890PX Systems Drive
890PXSA-43260M-H00-1A000	890PX Systems Drive
890PXSA-43300M-B00-1B3H0	890PX Systems Drive
890PXSA-43480M-H00-1A000	890PX Systems Drive
890PXSA-43580M-B00-1A000	890PX Systems Drive
890PXSA-43580M-B00-1A3P0	890PX Systems Drive
890PXSA-43580M-B00-1B0F0	890PX Systems Drive
890PXSA-63310M-B00-1A000	890PX Systems Drive
890SD/4/0420H/N/2F/A/UK	890SD/4/0420H/N/2F/A/UK
890SD-231300B0-B00-1A000	890 STANDALONE DRIVE
890SD-231300B0-B00-1B000	890 STANDALONE DRIVE
890SD-231550B0-B00-1B000	890 STANDALONE DRIVE
890SD-231700B0-B00-1A000	890 STANDALONE DRIVE
890SD-231700B0-B00-1A500	890SD AC DRIVE FRAME B
890SD-231700B0-B00-1B000	890 STANDALONE DRIVE
890SD-232110B0-B00-1A000	890 STANDALONE DRIVE
890SD-232110B0-B00-1A500	890SD AC DRIVE
890SD-232110B0-B00-1B000	890 STANDALONE DRIVE
890SD-232165B0-B00-1B000	890 STANDALONE DRIVE
890SD-232240C0-B00-1A600	890SD AC DRIVE
890SD-232240C0-B00-1B000	890 STANDALONE DRIVE
890SD-232300C0-B00-1A000	890 STANDALONE DRIVE
890SD-232300C0-B00-1B000	890 STANDALONE DRIVE
890SD-232300C0-B00-2A000	890 STANDALONE DRIVE
890SD-432730E0-B00-1A000	890 STANDALONE DRIVE
890SD-432730E0-B00-1A0P0	890 STANDALONE DRIVE
890SD-432730E0-B00-1A300	890 STANDALONE DRIVE
890SD-432730E0-B00-1A30A	890SD AC DRIVE
890SD-432730E0-B00-1A3P0	890 STANDALONE DRIVE
890SD-432730E0-B00-1A500	890 STANDALONE DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890SD-432730E0-B00-1A5F0	890SD AC DRIVE
890SD-432730E0-B00-1B000	890 STANDALONE DRIVE
890SD-432730E0-B00-1B1H0	890SD AC DRIVE
890SD-432730E0-B00-2B000	890 STANDALONE DRIVE
890SD-432870E0-B00-1A000	890 STANDALONE DRIVE
890SD-432870E0-B00-1A300	890 STANDALONE DRIVE
890SD-432870E0-B00-1A3P0	890 STANDALONE DRIVE
890SD-432870E0-B00-1A3PX	890SD AC DRIVE
890SD-432870E0-B00-1B000	890 STANDALONE DRIVE
890SD-432870E0-B07-1A000	890 STANDALONE DRIVE
890SD-432870E0-B07-1A100	890 STANDALONE DRIVE
890SD-432870E0-B07-1B000	890 STANDALONE DRIVE
890SD-433105F1-B00-1A000	890 STANDALONE DRIVE
890SD-433105F1-B00-1B000	890 STANDALONE DRIVE
890SD-433105F2-B00-1A000	890 STANDALONE DRIVE
890SD-433105F2-B00-1A300	890 STANDALONE DRIVE
890SD-433105F2-B00-1A30A	890SD AC DRIVE
890SD-433105F2-B00-1A3PA	890SD AC DRIVE
890SD-433105F2-B00-1B000	890 STANDALONE DRIVE
890SD-433145F1-B00-1A000	890 STANDALONE DRIVE
890SD-433145F1-B00-1A100	890 STANDALONE DRIVE
890SD-433145F1-B00-1A30A	890SD AC DRIVE
890SD-433145F1-B00-1B000	890 STANDALONE DRIVE
890SD-433145F1-B07-1A000	890 STANDALONE DRIVE
890SD-433145F2-B00-1A000	890 STANDALONE DRIVE
890SD-433145F2-B00-1A300	890 STANDALONE DRIVE
890SD-433145F2-B00-1A3P0	890 STANDALONE DRIVE
890SD-433156F1-B00-1A000	890 STANDALONE DRIVE
890SD-433156F1-B00-1B000	890 STANDALONE DRIVE
890SD-433156F1-B00-2A10A	890SD AC DRIVE
890SD-433156F2-B00-1A000	890 STANDALONE DRIVE
890SD-433156F2-B00-1A3P0	890SD AC DRIVE
890SD-433156F2-B00-1A5NR	890SD AC DRIVE
890SD-433156F2-B00-2A000	890 STANDALONE DRIVE
890SD-433180F1-B00-1A000	890 STANDALONE DRIVE
890SD-433180F1-B00-1A0H0	890 STANDALONE DRIVE
890SD-433180F1-B00-1A0HX	890SD AC DRIVE
890SD-433180F1-B00-1B000	890 STANDALONE DRIVE
890SD-433180F1-B07-1B000	890 STANDALONE DRIVE
890SD-433180F2-B00-1A0F0	890SD AC DRIVE
890SD-433180F2-B00-1A3P0	890 STANDALONE DRIVE
890SD-433180F2-B07-1A000	890SD AC DRIVE
890SD-433180F2-B07-1A0P0	890 STANDALONE DRIVE
890SD-433216G1-B00-1A000	890SD-433216G1-B00-1A000

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890SD-433216G2-B00-1A000	890 STANDALONE DRIVE
890SD-433250G1-000-1A000	890SD-433250G1-000-1A000
890SD-433250G2-000-1A3P0	890 STANDALONE DRIVE
890SD-433250G2-B00-1A000	890 STANDALONE DRIVE
890SD-433316G2-000-1A3P0	890 STANDALONE DRIVE
890SD-433361G1-000-1A000	890SD-433361G1-000-1A000
890SD-433361G1-B00-1A3P0	890 STANDALONE DRIVE
890SD-433361G2-B00-1A3P0	890 STANDALONE DRIVE
890SD-433361G2-B00-1A7P0	890 STANDALONE DRIVE
890SD-433520H2-000-1A3P0	890 STANDALONE DRIVE
890SD-433590J2-000-1A000	890SD-433590J2-000-1A000
890SD-433590J2-B00-1A000	890 STANDALONE DRIVE
890SD-531200B0-B00-1A000	890 STANDALONE DRIVE
890SD-531200B0-B00-1A0H0	890SD AC DRIVE FRAME B
890SD-531200B0-B00-1A0P0	890 STANDALONE DRIVE
890SD-531200B0-B00-1A1FX	890SD AC DRIVE FRAME B
890SD-531200B0-B00-1A1PA	890SD AC DRIVE FRAME B
890SD-531200B0-B00-1A1TA	890SD AC DRIVE FRAME B
890SD-531200B0-B00-1A30A	890 STANDALONE DRIVE
890SD-531200B0-B00-1A3E0	890 STANDALONE DRIVE
890SD-531200B0-B00-1A3EA	890 STANDALONE DRIVE
890SD-531200B0-B00-1A3P0	890 STANDALONE DRIVE
890SD-531200B0-B00-1A3TA	890 STANDALONE DRIVE
890SD-531200B0-B00-1A500	890 STANDALONE DRIVE
890SD-531200B0-B00-1A5P0	890 STANDALONE DRIVE
890SD-531200B0-B00-1B000	890 STANDALONE DRIVE
890SD-531200B0-B00-2A0P0	890SD AC DRIVE
890SD-531350B0-B00-1A000	890 STANDALONE DRIVE
890SD-531350B0-B00-1A0P0	890 STANDALONE DRIVE
890SD-531350B0-B00-1A0S0	890SD AC DRIVE FRAME B
890SD-531350B0-B00-1A100	890SD AC DRIVE
890SD-531350B0-B00-1A300	890 STANDALONE DRIVE
890SD-531350B0-B00-1A3H0	890SD AC DRIVE FRAME B
890SD-531350B0-B00-1A3P0	890 STANDALONE DRIVE
890SD-531350B0-B00-1A3PE	890SD AC DRIVE FRAME B
890SD-531350B0-B00-1A5N0	890SD AC DRIVE FRAME B
890SD-531350B0-B00-1B000	890 STANDALONE DRIVE
890SD-531350B0-B00-2A000	890 STANDALONE DRIVE
890SD-531350B0-B00-2A500	890SD AC DRIVE
890SD-531350B0-B00-2A5SA	890SD AC DRIVE FRAME B
890SD-531450B0-B00-1A000	890 STANDALONE DRIVE
890SD-531450B0-B00-1A0EA	890SD AC DRIVE FRAME B
890SD-531450B0-B00-1A0P0	890 STANDALONE DRIVE
890SD-531450B0-B00-1A300	890 STANDALONE DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**Тел. (499) 502 05 03, e-mail: info@tehzona.net,www.tehzona.net

890SD-531450B0-B00-1A3N0	890 STANDALONE DRIVE
890SD-531450B0-B00-1A3P0	890 STANDALONE DRIVE
890SD-531450B0-B00-1A3PA	890 STANDALONE DRIVE
890SD-531450B0-B00-1A500	890SD AC DRIVE FRAME B
890SD-531450B0-B00-1A5P0	890 STANDALONE DRIVE
890SD-531450B0-B00-1B000	890 STANDALONE DRIVE
890SD-531450B0-B00-2A000	890 STANDALONE DRIVE
890SD-531450B0-B00-2A3HA	890 STANDALONE DRIVE
890SD-531600B0-B00-1A000	890 STANDALONE DRIVE
890SD-531600B0-B00-1A0F0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1A0H0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1A0HA	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1A0P0	890 STANDALONE DRIVE
890SD-531600B0-B00-1A300	890 STANDALONE DRIVE
890SD-531600B0-B00-1A30A	890 STANDALONE DRIVE
890SD-531600B0-B00-1A3F0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1A3H0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1A3P0	890 STANDALONE DRIVE
890SD-531600B0-B00-1A3TA	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1A3TE	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1A5P0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1B000	890 STANDALONE DRIVE
890SD-531600B0-B00-1B0D0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1B3D0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-1B3H0	890SD AC DRIVE FRAME B
890SD-531600B0-B00-2A000	890 STANDALONE DRIVE
890SD-531600B0-B00-2A500	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1A000	890 STANDALONE DRIVE
890SD-532100B0-B00-1A0D0	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1A0P0	890 STANDALONE DRIVE
890SD-532100B0-B00-1A1H0	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1A1N0	890 STANDALONE DRIVE
890SD-532100B0-B00-1A300	890 STANDALONE DRIVE
890SD-532100B0-B00-1A30A	890 STANDALONE DRIVE
890SD-532100B0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532100B0-B00-1A3TA	890 STANDALONE DRIVE
890SD-532100B0-B00-1A5H0	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1A5N0	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1A5P0	890 STANDALONE DRIVE
890SD-532100B0-B00-1A70A	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1A7TA	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1B000	890 STANDALONE DRIVE
890SD-532100B0-B00-1B5H0	890SD AC DRIVE FRAME B
890SD-532100B0-B00-1B5SR	890SD AC DRIVE FRAME B

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890SD-532100B0-B00-2A000	890 STANDALONE DRIVE
890SD-532100B0-B00-2A3SA	890 STANDALONE DRIVE
890SD-532100B0-B00-2B000	890 STANDALONE DRIVE
890SD-532100B0-B00-2B1S0	890SD AC DRIVE
890SD-532120B0-B00-1A000	890 STANDALONE DRIVE
890SD-532120B0-B00-1A0N0	890SD AC DRIVE FRAME B
890SD-532120B0-B00-1A0NA	890SD AC DRIVE FRAME B
890SD-532120B0-B00-1A300	890 STANDALONE DRIVE
890SD-532120B0-B00-1A3H0	890SD AC DRIVE FRAME B
890SD-532120B0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532120B0-B00-1A500	890SD AC DRIVE
890SD-532120B0-B00-1A5P0	890 STANDALONE DRIVE
890SD-532120B0-B00-1B000	890 STANDALONE DRIVE
890SD-532120B0-B00-1B0P0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1A000	890 STANDALONE DRIVE
890SD-532160B0-B00-1A0F0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1A0H0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1A0N0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1A300	890 STANDALONE DRIVE
890SD-532160B0-B00-1A3N0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532160B0-B00-1A3S0	890SD AC DRIVE
890SD-532160B0-B00-1A3SE	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1A3T0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1A500	890 STANDALONE DRIVE
890SD-532160B0-B00-1B000	890 STANDALONE DRIVE
890SD-532160B0-B00-1B3H0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1B3P0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-1B5H0	890SD AC DRIVE FRAME B
890SD-532160B0-B00-2A000	890 STANDALONE DRIVE
890SD-532160B0-B00-2A100	890 STANDALONE DRIVE
890SD-532160B0-B00-2A300	890SD AC DRIVE FRAME B
890SD-532160B0-B00-2A3P0	890 STANDALONE DRIVE
890SD-53216SB0-B00-1A000	890 STANDALONE DRIVE
890SD-53216SB0-B00-1A0S0	890SD AC DRIVE
890SD-53216SB0-B00-1A3PA	890SD AC DRIVE FRAME B
890SD-53216SB0-B00-1A500	890SD AC DRIVE FRAME B
890SD-53216SB0-B00-1B000	890 STANDALONE DRIVE
890SD-53216SB0-B00-2A07A	890SD AC DRIVE FRAME B
890SD-53216SB0-B00-2A1NA	890SD AC DRIVE FRAME B
890SD-532240C0-B00-1A000	890 STANDALONE DRIVE
890SD-532240C0-B00-1A0N0	890 STANDALONE DRIVE
890SD-532240C0-B00-1A300	890 STANDALONE DRIVE
890SD-532240C0-B00-1A30A	890 STANDALONE DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890SD-532240C0-B00-1A30E	890SD AC DRIVE
890SD-532240C0-B00-1A3E0	890CD AC DRIVE
890SD-532240C0-B00-1A3H0	890SD AC DRIVE
890SD-532240C0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532240C0-B00-1A3T0	890SD AC DRIVE
890SD-532240C0-B00-1A500	890 STANDALONE DRIVE
890SD-532240C0-B00-1A50A	890SD AC DRIVE
890SD-532240C0-B00-1A5P0	890SD AC DRIVE
890SD-532240C0-B00-1A5TX	890SD AC DRIVE
890SD-532240C0-B00-1B000	890 STANDALONE DRIVE
890SD-532240C0-B00-1B0D0	890SD AC DRIVE
890SD-532240C0-B00-1B3H0	890SD AC DRIVE
890SD-532240C0-B00-2A500	890SD AC DRIVE
890SD-532300C0-B00-1A000	890 STANDALONE DRIVE
890SD-532300C0-B00-1A300	890SD AC DRIVE
890SD-532300C0-B00-1A3D0	890SD AC DRIVE
890SD-532300C0-B00-1A3H0	890SD AC DRIVE
890SD-532300C0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532300C0-B00-1A3PX	890SD AC DRIVE
890SD-532300C0-B00-1B000	890 STANDALONE DRIVE
890SD-532300C0-B00-1B3H0	890SD AC DRIVE
890SD-532300C0-B00-1B5SR	890SD AC DRIVE
890SD-532300C0-B00-2A000	890 STANDALONE DRIVE
890SD-532300C0-B00-2A500	890 STANDALONE DRIVE
890SD-532300C0-B00-2B000	890 STANDALONE DRIVE
890SD-53230SC0-B00-1A000	890 STANDALONE DRIVE
890SD-53230SC0-B00-1A500	890 STANDALONE DRIVE
890SD-53230SC0-B00-1A5P0	890SD AC DRIVE
890SD-532390D0-B00-1A000	890 STANDALONE DRIVE
890SD-532390D0-B00-1A0H0	890SD AC DRIVE
890SD-532390D0-B00-1A300	890 STANDALONE DRIVE
890SD-532390D0-B00-1A3D0	890SD AC DRIVE
890SD-532390D0-B00-1A3HX	890SD AC DRIVE
890SD-532390D0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532390D0-B00-1A5P0	890SD AC DRIVE
890SD-532390D0-B00-1B000	890 STANDALONE DRIVE
890SD-532390D0-B00-1B3H0	890SD AC DRIVE
890SD-532390D0-B00-1B5SR	890SD AC DRIVE
890SD-532390D0-B00-2B000	890 STANDALONE DRIVE
890SD-532450D0-B00-1A000	890 STANDALONE DRIVE
890SD-532450D0-B00-1A300	890 STANDALONE DRIVE
890SD-532450D0-B00-1A30A	890SD AC DRIVE
890SD-532450D0-B00-1A3F0	890 STANDALONE DRIVE
890SD-532450D0-B00-1A3H0	890SD AC DRIVE

**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net

890SD-532450D0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532450D0-B00-1A500	890 AC DRIVE
890SD-532450D0-B00-1B000	890 STANDALONE DRIVE
890SD-532450D0-B00-1B3H0	890SD AC DRIVE
890SD-532590D0-B00-0A000	890 STANDALONE DRIVE
890SD-532590D0-B00-1A000	890 STANDALONE DRIVE
890SD-532590D0-B00-1A300	890 STANDALONE DRIVE
890SD-532590D0-B00-1A3H0	890SD AC DRIVE
890SD-532590D0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532590D0-B00-1A3PE	890SD AC DRIVE
890SD-532590D0-B00-1A500	890 STANDALONE DRIVE
890SD-532590D0-B00-1A5R0	890SD AC DRIVE
890SD-532590D0-B00-1A600	890SD AC DRIVE
890SD-532590D0-B00-1B000	890 STANDALONE DRIVE
890SD-532590D0-B00-2A000	890 STANDALONE DRIVE
890SD-532730E0-B00-1A000	890 STANDALONE DRIVE
890SD-532730E0-B00-1A3P0	890 STANDALONE DRIVE
890SD-532730E0-B00-1B000	890 STANDALONE DRIVE
890SD-532730E0-B00-1B3H0	890SD AC DRIVE
890SD-532870E0-B00-1A000	890 STANDALONE DRIVE
890SD-532870E0-B00-1A300	890 STANDALONE DRIVE
890SD-532870E0-B00-1A30A	890SD AC DRIVE
890SD-532870E0-B00-1B000	890 STANDALONE DRIVE
890SD-532870E0-B00-1B3H0	890SD AC DRIVE
890SD-532870E0-B07-1A000	890 STANDALONE DRIVE
890SD-532870E0-B07-1A1PA	890 STANDALONE DRIVE
890SD-533105F1-B00-1A000	890 STANDALONE DRIVE
890SD-533105F1-B00-1B000	890 STANDALONE DRIVE
890SD-533105F2-B00-1A000	890 STANDALONE DRIVE
890SD-533105F2-B00-1A3PA	890 STANDALONE DRIVE
890SD-533105FA-B10-1A000	890 STANDALONE DRIVE SO10
890SD-533145F1-B00-1A000	890 STANDALONE DRIVE
890SD-533145F2-B00-1A000	890 STANDALONE DRIVE
890SD-533145F2-B07-1A0PA	890 STANDALONE DRIVE
890SD-533145FA-B10-1A000	890 STANDALONE DRIVE SO 10
890SD-533156F2-B00-1A000	890 STANDALONE DRIVE
890SD-533156F2-B07-1A000	890 STANDALONE DRIVE
890SD-533156F2-B07-1A0P0	890 STANDALONE DRIVE



**КОНФИГУРАЦИИ ИНВЕРТОРОВ PARKER
SSD AC 890**

Тел. (499) 502 05 03, e-mail: info@tehzona.net,
www.tehzona.net